



optocoupled input

OUT1:  
connected pins: 5-8 (Input 1 @ pin 5 etc.)  
usage:  
TPS: Input ports E1-E4 (connector SU2)  
ES-M32: OUT2 of 2nd input module (if used)

OUT2:  
connected pins: 1-4 (Input 1 @ pin 1 etc.)  
usage:  
TPS: do NOT connect TPS to OUT2  
ES-M32: connect to port pins of ES-M32